

Skoda **V26.30** Diagnostics List (Note: For reference only)

MODEL	TYPE	SYSTEM	Functions
Fabia I	6Y	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
Fabia II	5J	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

Skoda **V26.30** Diagnostics List (Note: For reference only)

MODEL	TYPE	SYSTEM	Functions
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Felicia	6U	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		41 Diesel pump electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Octavia I	1U	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		29 Left light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

Skoda **V26.30** Diagnostics List (Note: For reference only)

MODEL	TYPE	SYSTEM	Functions
		39 Right light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Octavia II	1Z	01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		3D Special Function	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS		
47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		

Skoda V26.30Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	Functions
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		76 Parking aid	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		7D Auxiliary Heater	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
Roomster	5J	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		

Skoda **V26.30** Diagnostics List (Note: For reference only)

MODEL	TYPE	SYSTEM	Functions
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Superb I	3U	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03
		15 Airbags	B01,B02,B08,B05,S04,S10,B03
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03

Skoda **V26.30** Diagnostics List (Note: For reference only)

MODEL	TYPE	SYSTEM	Functions
Superb II	3T	18 Aux heating	B01,B02,B08,B05,S04,S10,B03
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03
		37 Navigation	B01,B02,B08,B05,S04,S10,B03
		3D Special Function	B01,B02,B08,B05,S04,S10,B03
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03
		4F Electronic central electric II	B01,B02,B08,B05,S04,S10,B03
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03
		56 Radio	B01,B02,B08,B05,S04,S10,B03
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03
		62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03
		72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03
		76 Parking aid	B01,B02,B08,B05,S04,S10,B03
77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03		
7D Auxiliary Heater	B01,B02,B08,B05,S04,S10,B03		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03

Skoda **V26.30** Diagnostics List (Note: For reference only)

MODEL	TYPE	SYSTEM	Functions
Yeti	5L	08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03
		15 Airbags	B01,B02,B08,B05,S04,S10,B03
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03
		37 Navigation	B01,B02,B08,B05,S04,S10,B03
		3D Special Function	B01,B02,B08,B05,S04,S10,B03
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03
		4F Electronic central electric II	B01,B02,B08,B05,S04,S10,B03
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03
55 Headlight range control	B01,B02,B08,B05,S04,S10,B03		
56 Radio	B01,B02,B08,B05,S04,S10,B03		
62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03		
69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03		
72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03		

Skoda V26.30 Diagnostics List (Note: For reference only)			
MODEL	TYPE	SYSTEM	Functions
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03

NOTE:

B01:01 Control Unit Info

B02:02 Read Fault Codes

B08:08 Measuring Blocks (Live Data)

B05:05 Clear Fault Codes

BIS:identification services

B15:15 Readiness

B09:09 Single Reading

B03:03 Output Tests

S04:04 Basic Settings

S10:10 Adaptation

S07:07 Code Module

S11L:11 Login

SCA:Chassis Number adjustment

S11C:11 code module

S16:16 Access permission

SLC:Long Code

(*):Tested;

(?):Manual on website(www.x431.com)

NOTE:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD

CONNECTOR	X431/TOOL	DIAGUN
OBD 16C	Skoda Model of non-CAN BUS protocol	N/A
CANBUS II	All Skoda Models with 16PIN DLC	N/A
SUPER 16	All Skoda Models with 16PIN DLC	N/A
diagun connector	N/A	All Skoda Models with 16PIN DLC