

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Caddy	9K	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Caddy	2K	01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		3D Special Function	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		76 Parking aid	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		7D Auxiliary Heater	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
Corrado	50	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Golf Cabrio	1E	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Eos	1F	16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		1C Vehicle Position Detection	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		26 Electric roof control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		65 Type pressure monitoring	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		63 DRVS BOARDING ASS1	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		73 DRVS BOARDING ASS2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		76 Parking aid	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S07
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S07

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Fox	5Z	08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S07
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,S07
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S07
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S07
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,S07
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S07
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,S07
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S07
Golf Citi	17	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Golf/Jetta II	1G	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Golf/Vento III	1H	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		12 Clutch electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		41 Diesel pump electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Golf/Bora IV	1J	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S07,S11C,S16
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		29 Left light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		39 Right light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Jetta IV	9M	08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		29 Left light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		39 Right light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		0F Radio Tuner-Digital	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Golf/Jetta V	1K	15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		1C Vehicle Position Detection	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		3D Special Function	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		4F Electronic central electric II	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
65 Type pressure monitoring	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		76 Parking aid	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		7D Auxiliary Heater	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
Golf/Jetta VI	5K	01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		0F Radio Tuner-Digital	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		13 Distance control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		14 Wheel damping electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		1C Vehicle Position Detection	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		



## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		4F Electronic central electric II	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		5F Information Electronic Equipment 1	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		65 Type pressure monitoring	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
Gol/Par/Sav/Poi	5W	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Gol/Par/Sav/Poi	5X	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Gol Special	5Y	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
New Beetle	1C	08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		26 Electric roof control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		29 Left light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		39 Right light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		54 Rear spoiler	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
New Beetle NAR	AG	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		26 Electric roof control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		29 Left light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		39 Right light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		54 Rear spoiler	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
New Beetle	9C	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		26 Electric roof control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		29 Left light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		39 Right light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		54 Rear spoiler	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
New Beetle Cab	1Y	03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		26 Electric roof control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		29 Left light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		39 Right light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		54 Rear spoiler	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
75 Emergency call module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
New Beetle Cab NAR	AL	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		26 Electric roof control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		29 Left light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		39 Right light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		54 Rear spoiler	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
New Bora	15	01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		15 Airbags	B01,B02,B08,B05
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,SLC,S16
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
Lavida	18	01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		15 Airbags	B01,B02,B08,B05
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
Lupo	6X	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		45 Interior Monitoring	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Passat B3	31	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Passat B4	3A	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		41 Diesel pump electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Passat B5	3B	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		58 Auxiliary Fuel Tank	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
77 TELEPHONE	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		05 ACCESS & PERMISSI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Passat B6	3C	08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		0F Radio Tuner-Digital	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		13 Distance control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		1C Vehicle Position Detection	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		3D Special Function	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
53 Parking Brake	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		



## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		5D Opertion	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		65 Type pressure monitoring	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		6C Rear Camera	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		6D Electronic Equipment of Trunk Lid	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		76 Parking aid	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		7D Auxiliary Heater	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		0F Radio Tuner-Digital	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		13 Distance control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		14 Wheel damping electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		1C Vehicle Position Detection	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Passat CC	35	22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		4F Electronic central electric II	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		53 Parking Brake	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		5C Lane Keeping Assistance System	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		65 Type pressure monitoring	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		6C Rear Camera	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		05 ACCESS & PERMISSI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		06 PASSENE. SEAT ADJ.	B01,B02,B08,B05,S04,S10,B03,S11C,S16

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Phaeton D1	3D	07 DISPLAY-/CNTL UNIT	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		11 Engine electronics 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		13 Distance control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		23 BRAKER BOOSTER	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		27 DIS./CTL UNIT REAR	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		28 Climate Control Unit Rear	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		29 Left light control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		34 Self leveling suspension	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		38 ROOF ELECTRONICS	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		39 Right light control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16		
57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03,S11C,S16		

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		65 Type pressure monitoring	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		66 Seat-/mirror adjust.	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		68 WIPER ELECTRONICS	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		71 Battery charger	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		76 Parking aid	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16
Polo	6N	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		41 Diesel pump electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		45 Interior Monitoring	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Polo Classic	6V	17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Polo	9N	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		45 Interior Monitoring	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Polo	6R	10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
Scirocco	13	01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		14 Wheel damping electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Scirocco	1J	2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		3D Special Function	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		65 Type pressure monitoring	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
Sharan I	7M	25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		18 Aux heating	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		29 Left light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		39 Right light control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		45 Interior Monitoring	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Tiguan	5N	01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		25 Immobilizer	B01,B02,B05
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS



## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		4F Electronic central electric II	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		53 Parking Brake	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		6C Rear Camera	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Tiguan NAR	AX	19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		25 Immobilizer	B01,B02,B05
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		4F Electronic central electric II	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		53 Parking Brake	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		6C Rear Camera	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		05 ACCESS & PERMISSI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Touareg	7L	06 PASSENE. SEAT ADJ.	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		11 Engine electronics 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		13 Distance control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		1C Vehicle Position Detection	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		29 Left light control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		32 Locking Electronisc	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		34 Self leveling suspension	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		39 Right light control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		3C Lane Departure Assistance System	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16
57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03,S11C,S16		
64 Stabilizers	B01,B02,B08,B05,S04,S10,B03,S11C,S16		

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
		65 Type pressure monitoring	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		68 WIPER ELECTRONICS	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		6C Rear Camera	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		6D Electronic Equipment of Trunk Lid	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		6E Roof Display/Control Head	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		76 Parking aid	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		05 ACCESS & PERMISSI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		06 PASSENE. SEAT ADJ.	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		11 Engine electronics 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		13 Distance control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		1C Vehicle Position Detection	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Touareg NAR	A9	29 Left light control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		32 Locking Electronic	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		34 Self leveling suspension	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		36 Driver`s side seat adj.	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		39 Right light control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		3C Lane Departure Assistance System	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		64 Stabilizers	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		65 Type pressure monitoring	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		68 WIPER ELECTRONICS	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		6C Rear Camera	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		6D Electronic Equipment of Trunk Lid	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		6E Roof Display/Control Head	B01,B02,B08,B05,S04,S10,B03,S11C,S16
		75 Emergency call module	B01,B02,B08,B05,S04,S10,B03,S11C,S16
76 Parking aid	B01,B02,B08,B05,S04,S10,B03,S11C,S16		
77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Transporter	70	08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
Transporter	7D	01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		35 Central Locking	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		0B Auxiliary Air Heater	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		0D Sliding Door Left	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		15 Airbags	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Transporter	7H	17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		18 Aux heating	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		1C Vehicle Position Detection	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		2D Voice Amplification	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		37 Navigation	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		45 Interior Monitoring	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		56 Radio	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		6E Roof Display/Control Head	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		76 Parking aid	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15
78 SLIDING DOOR	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
7D Auxiliary Heater	B01,B02,B08,B05,S04,S10,B09,B03,S07,S11L,SCA,B15		
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		0B Auxiliary Air Heater	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		0D Sliding Door Left	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Transporter	7E	13 Distance control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SLC,S16,BIS
		22 4WD Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		2D Voice Amplification	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		3C Lane Departure Assistance System	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		57 TV-TUNER	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		6C Rear Camera	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		6E Roof Display/Control Head	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		78 SLIDING DOOR	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		01 Engine electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		02 Transmission Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		03 Brake Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		08 AC/Heating electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		09 Electronic Ctrl Electronics	B01,B02,B08,B05,S04,S10,B03,SCL,S16,BIS
		10 Parking Assist System 2	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS



## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
Touran	1T	15 Airbags	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		16 Steering Wheel Electronics	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		17 Instrument Cluster	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		18 Aux heating	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		19 Gateway data bus	B01,B02,B08,B05,S04,S10,B03,SCL,S16,BIS
		25 Immobilizer	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		2E Media player position 3	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		37 Navigation	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		3D Special Function	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		42 DRIVER-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		44 Steering assistance	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		46 Central Control Module	B01,B02,B08,B05,S04,S10,B03,SCL,S16,BIS
		47 Soundsystem	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		52 PASSE.-DOOR ELECT.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		55 Headlight range control	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		56 Radio	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		62 LR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		69 TRAILER FUNCTION	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		72 RR-DOOR ELECTRONI.	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
		76 Parking aid	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS
77 TELEPHONE	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		
7D Auxiliary Heater	B01,B02,B08,B05,S04,S10,B03,S11C,S16,BIS		

NOTE:

## Volkswagen **V26.30** Diagnostics List (Note:For reference only)

MODEL	TYPE	SYSTEM	FUNCTIONS
-------	------	--------	-----------

B01: 01 Control Unit Info

B02: 02 Read Fault Codes

B08: 08 Measuring Blocks (Live Data)

B05: 05 Clear Fault Codes

BIS: identification services

B15: 15 Readiness

B09: 09 Single Reading

B03: 03 Output Tests

S04: 04 Basic Settings

S10: 10 Adaptation

S07: 07 Code Module

S11L: 11 Login

SCA: Chassis Number adjustment

S11C: 11 code module

S16: 16 Access permission

SLC: Long Code

(\*):Tested;

(?):Manual on website([www.x431.com](http://www.x431.com))

NOTE:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD

<b>CONNECTOR</b>	<b>X431/TOOL</b>	<b>DIAGUN</b>
OBD 16C	VW Model of non-CAN BUS protocol	N/A
CANBUS II	All VW Models with 16PIN DLC	N/A
SUPER 16	All VW Models with 16PIN DLC	N/A
diagun connector	N/A	All VW Models with 16PIN DLC